

## **ROP-KEY-U**

## SPARE KEY FOR ROP-110/111 AND ROP-400/401 (10-PACK)

The **ROP–KEY–U** is designed to be used with the **ROP–110**, **ROP–111**, **ROP–400** and **ROP–401** manual call points. It enables manual testing of their correct operation, as well as resetting the activated manual call points by restoring the pressed plastic pane to its original position.

- designed to work with ROP-110/EU, ROP-111/EU, ROP-400/EU, ROP-401/EU
- key enables:
  - testing
  - resetting
- pack contains 10 keys

