

# RJ/PIN5

## RS-232 CABLE

RJ/PIN5 is a cable for connecting RS ports of **INTEGRA** control panels provided with RJ socket with communication modules having PIN-5 connector, i.e. GSM, ISDN-MOD, ETHM-1, ETHM-1 Plus, as well as MDM56 BO modem.

- cable for connection of RS Ports of **INTEGRA** panels equipped with RJ connector and modules equipped with PIN-5 connector (**MDM56 BO** modems, **GSM, ISDN-MOD, ETHM-1, ETHM-1 Plus** modules)

